



Technical Manual for Dual-Level

1 Compartment Dual-Level Overfill Prevention Monitoring System for Tank Truck Loading

Featuring Dynamic Self-Checking® www.scully.com

Table of Contents

2.1 IntelliCheck®3R and Socket Installation 2.2 Overfill Sensors Mounting 3. Electrical Installation 3.1 IntelliCheck®3R Power Wiring 3.2 Truck Sensor Wiring - General 4. On Vehicle Programming 20. 5. Sensor Wiring 5.1 Two-Wire Sensor Wiring	1. General In	formation	1.
1.3 Intrinsic Safety Entity Parameters 1.4 Standards 1.5 Compliance Label 2. Mechanical Installation 2.1 IntelliCheck®3R and Socket Installation 2.2 Overfill Sensors Mounting 3. Electrical Installation 3.1 IntelliCheck®3R Power Wiring 3.2 Truck Sensor Wiring - General 4. On Vehicle Programming 20. 5. Sensor Wiring 5.1 Two-Wire Sensor Wiring 6. Socket & Switch Wiring 6.1 Five-Wire Optic Connection 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output	1.1	Technical Specifications	
1.4 Standards 1.5 Compliance Label 2. Mechanical Installation 2.1 IntelliCheck®3R and Socket Installation 2.2 Overfill Sensors Mounting 3. Electrical Installation 3.1 IntelliCheck®3R Power Wiring 3.2 Truck Sensor Wiring - General 4. On Vehicle Programming 20. 5. Sensor Wiring 5.1 Two-Wire Sensor Wiring 6. Socket & Switch Wiring 6.1 Five-Wire Optic Connection 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output	1.2	Approvals	
1.5 Compliance Label 2. Mechanical Installation 2.1 IntelliCheck®3R and Socket Installation 2.2 Overfill Sensors Mounting 3. Electrical Installation 3.1 IntelliCheck®3R Power Wiring 3.2 Truck Sensor Wiring - General 4. On Vehicle Programming 20. 5. Sensor Wiring 5.1 Two-Wire Sensor Wiring 6. Socket & Switch Wiring 6.1 Five-Wire Optic Connection 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output	1.3	Intrinsic Safety Entity Parameters	
2. Mechanical Installation 2.1 IntelliCheck®3R and Socket Installation 2.2 Overfill Sensors Mounting 3. Electrical Installation 3.1 IntelliCheck®3R Power Wiring 3.2 Truck Sensor Wiring - General 4. On Vehicle Programming 20. 5. Sensor Wiring 5.1 Two-Wire Sensor Wiring 6. Socket & Switch Wiring 6.1 Five-Wire Optic Connection 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output	1.4	Standards	
2.1 IntelliCheck®3R and Socket Installation 2.2 Overfill Sensors Mounting 3. Electrical Installation 3.1 IntelliCheck®3R Power Wiring 3.2 Truck Sensor Wiring - General 4. On Vehicle Programming 20. 5. Sensor Wiring 5.1 Two-Wire Sensor Wiring 6. Socket & Switch Wiring 6.1 Five-Wire Optic Connection 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output	1.5	Compliance Label	
2.2 Overfill Sensors Mounting 3. Electrical Installation 3.1 IntelliCheck®3R Power Wiring 3.2 Truck Sensor Wiring - General 4. On Vehicle Programming 20. 5. Sensor Wiring 5.1 Two-Wire Sensor Wiring 6. Socket & Switch Wiring 6.1 Five-Wire Optic Connection 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output	2. Mechanica	al Installation	10.
3. Electrical Installation 3.1 IntelliCheck®3R Power Wiring 3.2 Truck Sensor Wiring - General 4. On Vehicle Programming 20. 5. Sensor Wiring 5.1 Two-Wire Sensor Wiring 6. Socket & Switch Wiring 6. Socket & Switch Wiring 6.1 Five-Wire Optic Connection 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output	2.1	IntelliCheck®3R and Socket Installation	
3.1 IntelliCheck®3R Power Wiring 3.2 Truck Sensor Wiring - General 4. On Vehicle Programming 20. 5. Sensor Wiring 5.1 Two-Wire Sensor Wiring 6. Socket & Switch Wiring 6.1 Five-Wire Optic Connection 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output	2.2	Overfill Sensors Mounting	
3.2 Truck Sensor Wiring - General 4. On Vehicle Programming 20. 5. Sensor Wiring 5.1 Two-Wire Sensor Wiring 6. Socket & Switch Wiring 6.1 Five-Wire Optic Connection 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output	3. Electrical	Installation	13.
4. On Vehicle Programming 20. 5. Sensor Wiring 5.1 Two-Wire Sensor Wiring 6. Socket & Switch Wiring 6.1 Five-Wire Optic Connection 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output	3.1	IntelliCheck®3R Power Wiring	
5. Sensor Wiring 5.1 Two-Wire Sensor Wiring 6. Socket & Switch Wiring 6.1 Five-Wire Optic Connection 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output	3.2	Truck Sensor Wiring - General	
5.1 Two-Wire Sensor Wiring 6. Socket & Switch Wiring 6.1 Five-Wire Optic Connection 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output	4. On Vehicle	Programming	20.
6. Socket & Switch Wiring 23. 6.1 Five-Wire Optic Connection 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output	5. Sensor Wi	ring	21.
 6.1 Five-Wire Optic Connection 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output 	5.1	Two-Wire Sensor Wiring	
 6.2 Two-Wire Optic (Thermistor) Connection 6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output 	6. Socket & S	Switch Wiring	23.
6.3 Auxiliary Switch Input 6.4 Non Intrinsically Safe (Non I.S.) Relay Output	6.1	Five-Wire Optic Connection	
6.4 Non Intrinsically Safe (Non I.S.) Relay Output	6.2	Two-Wire Optic (Thermistor) Connection	
,	6.3	Auxiliary Switch Input	
6.5 Intrinsically Safe (I.S.) Relay Output	6.4	Non Intrinsically Safe (Non I.S.) Relay Output	
	6.5	Intrinsically Safe (I.S.) Relay Output	

Table of Contents

7. Cover Tightening		27.
8. Operation	ns	28.
8.1	Sensor Diagnostics	
8.2	Intellicheck®3R System Diagnostics	
8.3	Technical Service	
9. Control D	Prawing	33.
10. Appendix		34.
11. Parts Lis	st	36.

1. General Information

IntelliCheck®3 Family Description

The IntelliCheck®3R System is a family of point level detection systems designed to prevent overfill and spillage of product.

The product list includes:

Overfill 8 Detects overfilling for up to 8 compartments
Overfill/Retained Detects overfilling and retained product for up

to 8 compartments

Dual - Level Detects two levels of filling in 1 compartment.

The IntelliCheck®3R System is an ideal secondary overfill protection system for a wide range of environments and product types.

Dual - Level Overfill Features:

The IntelliCheck®3R Dual-Level Overfill offers a range of features including:

- Dual-Level Detection Overfill prevention for 1 compartment.
- Auxiliary input
- Supports Scully's Dynacheck® automatic and continuous self-checking circuitry.
- Bicolor LEDs providing complete system diagnostics, includes sensors, power, and rack connection
- Corrosion-resistant housing
- Scratch-resistant window
- Compatible with Scully's SP-TO Two-Wire Optic Sensors
- Intrinsically safe and non-intrinsically safe relay outputs.

The IntelliCheck®3R Dual-Level Overfill is suitable for use on single compartment vehicles which require two levels of monitoring. The IntelliCheck®3R Dual-Level System is pre-configured for ONE vehicle compartment to ensure maximum safety for proper sensor response should a high or high-high level (overfill) condition occur.

1. General Information

Installation does NOT require dummy loads or "terminators" which may be used to bypass failed sensors or imitate sensors that are not installed.

The IntelliCheck®3R System offers compatible outputs for connection to either a Two-Wire Optical (Thermistor) or Five-Wire Optics-equipped loading terminal rack controls.

Relay output provisions are included for intrinsically safe and non-intrinsically safe relay connections, for control of vehicle mounted devices. A typical device would be an air/electrically operated bottom loading valve commonly used in the aviation industry.

All IntelliCheck®3R Systems include superior diagnostics for sensor status as well as bicolor LED indication of monitor operation, indication of proper loading rack connection and self-checking Dynacheck® operation.

The IntelliCheck®3R System module is installed in a corrosion resistant housing that features ample wiring room, allowing for easy installation and serviceability. It also features a scratch-resistant window for viewing of the unit's diagnostic indicators. For indicator light explanations refer to the Quick Start Guide, the Troubleshooting guide, or the operation section of this manual for fast problem-solving. The IntelliCheck®3R System provides the user Faylsafe® operation when loading at terminals requiring secondary overfill prevention. Faylsafe® operation is incorporated into the Scully design technology by utilizing Dynacheck®, Scully's unique automatic and continuous self-checking feature. This feature ensures the IntelliCheck®3R monitor and sensors are being continuously checked for proper operation including wiring and connections. Should a sensor become wet or a fault develops due to component failure or wiring, the outputs to the loading rack controllers are disabled (non-permit condition). All control outputs also operate in a Faylsafe® manner.

1. General Information

Dual - Level Specific Operations

The IntelliCheck®3R Dual-Level System is pre-configured for ONE vehicle compartment to ensure maximum safety for proper sensor response should a high or a high-high level (overfill) condition occur. Only 2-Wire optical sensors are allowed.

As mentioned above, the IntelliCheck®3R Dual-Level System is pre-configured for ONE compartment. The monitor CANNOT be manually reprogrammed to any more compartments and the On Board Programming is disabled.

The Dual-Level monitor is configured to detect two different fluid levels and provide two seperate outputs, one output respectively for each level detected.

The lower level, referred to as High, when wet will signal a non-permit via output to the standard API optical and thermistor sockets AND open the I.S. relay on TB6.

The higher second level, referred to as High-High, when wet will signal a non-permit via output to the standard API optical and thermistor sockets AND open the non-I.S. relay on TB7.

1. General Information

A Summary of the operation is shown in the table below:

	High Sensor	High-High Sensor	I.S. Output Relay (TB6)	Non-I.S. Output Relay (TB7)	API Socket Output
Case 1	Dry	Dry	Closed	Closed	Permit
Case 2	Wet	Dry	Open	Closed	Non-Permit
Case 3	Wet	Wet	Open	Open	Non-Permit
Case 4	Dry	Wet	Open	Open	Non-Permit

The High sensor deactivates the I.S. open relay (TB6) and causes a non-permit.

The High-High sensor deactivates both the I.S. (TB6) and Non-I.S. (TB7) relays and causes a non-permit.

The use of the Dual-Level monitor allows for two different levels of detection and two outputs. For example, a vehicle is loading, if the high sensor gets wet, the IntelliCheck®3R Dual-Level signals the rack to shut down and opens the I.S. output relay, which could go to the PLC. If for some reason, the rack valve doesn't respond to the shut down command, and the High-High sensor gets wet, then the IntelliCheck®3R Dual-Level signals to the rack again to shut down. It also makes sure the I.S. relay is open and additionally opens the non-I.S. relay, which could close the truck input valve to close, thus preventing a spill. So, in this case, the IntelliCheck®3R Dual-Level can prevent a spill even if the truck valve fails.

1. General Information

1.1 Technical Specifications

Temperature Range

Operating: -40 to +60 Degrees C (-40 to +140 Degrees F)
Storage: -45 to +85 Degrees C (-50 to +185 Degrees F)

Power Requirement:

Nominal Voltage: 12 to 24 VDC (-0.5, +8 VDC)

Consumption: 9.6 Watts maximum at 24 VDC

4.8 Watts maximum at 12 VDC

Outside Dimensions: 9.26" wide X 6.81" high X 2.54" deep

Weight: 2.7 kg (6.lb)

Interfaces

Inputs: • TB4 & TB5 Sensor Inputs: EN 13922 compliant

• TB4 & TB5 Sensor Inputs: 2-Wire Optic only

• TB3 Auxiliary: I.S. input switch closure less than 100 ohms

Outputs:

 TB7: 2.0A at 32 VDC maximum Non-intrinsically safe relay

• TB6 Rack interface: EN 13922 compliant I.S. interface for 2/5- wire sensors

 TB6: Intrinsially safe relay output. 200mA at 32 VDC maximum or 500mA at 16 VDC maximum

1.2 Approvals

IntelliCheck®3R has safety approvals as an intrinsically safe monitoring device for use in:

• Class I, Division 2, Group CD, T6, Type 4 or

Class I, Zone 2, IIB T6, IP 65

With intrinsically safe outputs for

Class I, Division 1, Group CD

Class 1, Zone 0, IIB Locations

Ambient temperature for all ratings (Ta < -40°C to +60°C)

1. General Information

• Europe:

IECEX ETL 15.0004 ITS15ATEX58179 (Ex logo) II 2(1)G Ex e mb [ia] IIB T4 Gb -40°C < Ta < +60°C

MARNING: Exposure to some chemicals may degrade the sealing properties of materials used in the sealed module device.

WARNING: Explosion hazard- do not remove or replace lamps, fuses or plug-in modules unless power has been disconnected or the area is known to be free of ignitable concentrations of ammable gases or vapors.

WARNING: Explosion hazard – do not disconnect equipment while the circuit is live or unless the area is known to be free of ignitable concentrations.

WARNING: Explosion hazard – substitution of components may impair suitability for class 1, division 2.

WARNING: Cable glands, cables, and conduit at cable entry points must be rated to an operating temperature of 67.6°C or higher.

AVERTISSEMENT: L'exposition à certains produits chimiques peut dégrader les propriétés d'étanchéité des matériaux utilisés dans les module étanche périphérique.

AVERTISSEMENT: Risque d'explosion – ne pas debrancher tant que le circuit est sous tension, a moins qu'il ne s'agisse d'un emplac ment non dangereux.

AVERTISSEMENT: Risque d'explosion – ne débranchez pas l'équipement pendant que le circuit est direct ou à moins que l'environnement soit connu pour être libre de concentrations in ammables.

AVERTISSEMENT: Risque d'explosion- la substitution de coposants peut rendre ce materiel inacceptable pour les emplacements de classe 1, division 2.


AVERTISSEMENT: Les presse-étoupes, les câbles et conduits aux points d'entrée des câbles doivent être prévus pour une température de service nominale de 67.6 C ou plus.

1. General Information

Additional important information:

- It is recommended that the vehicle not be running during the use of the IntelliCheck®3R.
- It has an enclosure rating Type 4/IP65. The design provides protection against windblown dust and rain, splashing water, hose directed water and is undamaged by the formation of ice on the enclosure.
- This system complies with clause 6.3.13 of UL 60079-11:2009
- The IntelliCheck®3R power wiring should contain a switch and an inline fuse (included) that is installed in a safe area.
- The switch allows the IntelliCheck®3R to be turned off when not needed. It is recommended that the IntelliCheck®3R be turned off when not in use.
- IntelliCheck®3R has been designed to be impact-resistant and is designed to withstand typical vibrations encountered in road transport. It should not be subjected to excessive mechanical or thermal stresses.
- Do not allow the unit to come in contact with aggressive substances.
- Do not allow build-up of dust on the monitor.
- Electrical repair is limited to replacing the internal module with an equivalent Scully IntelliCheck®3R module.
- Wiring to and from the IntelliCheck®3R must conform to wiring techniques specified for its area classification.

1.3 Intrinsic Safety Entity Parameters:



1. General Information

1.4 Standards

United States and Canada

- UL 913, Ed:8 Rev:2015 UL Standard for Safety:
 - -Intrinsically Safe Apparatus and Associated Apparatus for Use in Class I, II and III, Division 1, Hazardous Locations
- UL 121201:2017 Ed. 9

Non-Incendive Electrical Equipment for Use in Class I and II, Division 2 and Class III, Divisions 1 and 2 Hazardous Locations

- UL 60079-0:2019 Ed.7 Explosive Atmospheres
 - Part 0: Equipment General Requirements
- UL 60079-11:2013 Ed. 6 Explosive Atmospheres
 - Part 11: Equipment Protection By Intrinsic Safety "I"
- UL 60079-26:2017 Ed.3 Explosive Atmospheres
 - Part 26: Equipment with Equipment Protection Level (EPL) Ga
- UL 61010-1:2012 Ed.3+R 2018 Electrical Equipment for Measurement, Control, and Laboratory Use
 - Part 1: General Requirements
- UL 61010-2-201:2018 Ed.2 Safety Requirements For Electrical Equipment For Measurement, Control, And Laboratory Use
 Part 2-201: Particular Requirements For Control Equipment
- CSA C22.2#60079-0:2019 Ed.4 Explosive Atmospheres
 - Part 0: Equipment General Requirements
- CSA C22.2#213:2017 Ed.3+U1;U2 Non-Incendive Electrical Equipment for Use in Class I and II, Division 2 and Class III, Divisions 1 and 2 Hazardous Locations
- CSA C22.2#60079-11:2014 Ed.2 Explosive Atmospheres
 Part 11: Equipment Protection By Intrinsic Safety "I"
- CSA C22.2#61010-1-12:2012 Ed.3+U1;U2;A1Safety Requirements
 For Electrical Equipment For Measurement, Control, And
 Laboratory Use
 - Part 1: General Requirements
- CSA C22.2#61010-2-201:2018 Ed.2 Safety Requirements For Electrical Equipment For Measurement, Control, And Laboratory Use
 - Part 2-201: Particular Requirements For Control Equipment
- NEMA 250-2008 Enclosures for Electrical Equipment (1000 Volts Maximum)
- FCC 47CFR PT 15 SPT B Issued: 2013/01/28 Title 47 CFR Part 15 Subpart B: Unintentional Radiators

General Information 1.

EMC Compatible:

- IEC 61000-4-2 issue:2008/12/09 ed:2 Electromagnetic compatibility (emc) - part 4-2:testing and measurement techniques
 - Electrostatic discharge immunity test
- IEC 61000-4-3 Issue:2010/04/27 Ed:3.2 (EMC) Part 4-3: Testing and Measurement Techniques - Radiated, Radio-Frequency, Electr magnetic Field Immunity Test
- IEC 61000-4-4, issue:2011/03/30 ed:2.1 Electromagnetic Compatibility (emc) – part 4-4: Testing and measurement techniques - Electrical fast transient/burst immunity test
- IEC 61000-4-6, issue:2008/10/31 ed:3 Electromagnetic compatibility (emc) - part 4-6:testing and measurement techniques - Immunity to conducted disturbances, induced by radio-frequency fields
- IEC 61000-2-3 30 A/m, 50Hz and 60 Hz, Power Frequency Magnetic Field Immunity

Europe:

- IEC 60079-0:2018 Explosive atmospheres
 - Part 0: General requirements
- IEC 60079-7:2015 Explosive atmospheres
 - Part 7: Equipment protection by increased safety "e"
- IEC 60079-11:2012 Explosive atmospheres
 - Part 11: Equipment protection by intrinsic safety "i"
- IEC 60079-18:2015/AC2018-09 Explosive atmospheres
 - Part 18: Equipment protection by encapsulation "m"

1.5 Compliance Label



HAZARDOUS LOCATION CONFORMS TO STANDARDS: UL 61010-1, 61010-2-201, 913, 121201 CERTIFIED TO STANDARDS: ETL14CA101487821 CSA C22.2#61010-1-12, 61010-2-201, 60079-0, 60079-11, 213 [Ex ia IIB Ga]

LISTED 69126 ITS15ATEX58179 IECEX ETL 15.0004 ITS22UKEX0559 Ex eb mb [ia Ga] IIB T4 Gb, IP65

Complies with EN/IEC 13922 Complies with 47 CFR part 15 subpart B

ASSOCIATED FOLIRMENT APPAREILL AGE CONNEXE ASSOCIATED EQUIPMENT, APPAREILLAGE CONDEX, Class I, Zone 2, IB T6, IP65 Qutdoor Lagroup Co T5, Type 4; Class I, Zone 2, IB T6, IP65 Qutdoor hazardous locations with intrinsically safe outputs to Class I, Division 1, Group Co. Class I; Zone 0, IB hazardous locations, in accordance with Sculp Co. Class I; Zone 0, IB hazardous locations, in accordance with Sculp Co. Class I; Zone 1, IB hazardous locations, in accordance with Sculp Co. Class I; Zone 1, IB hazardous locations, in accordance with Sculp Co. Class I; Zone 1, IB Lagrandous Co. Class III Class III Co. Class III Class I

Warning: Improper connections, component substitution o tampering may impair intrinsic safety and create hazardous conditions.

Avertissement: Des connections mal effectuées, la

substitution ou la manipulation des composants peuvent nuire à la Sécurité intrinsèque et créer des conditions dangereuses.

ATENÇÃO - NÃO ABRA QUANDO ENERGIZADO ATENÇÃO - NÃO ABRA QUANDO UMA ATMOSFERA EXPLOSIVA ESTIVER PRESENTE Veia o manual on Website www.scully.com



Mechanical Installation 2.

Locating and mounting the IntelliCheck®3R monitor, sockets and overfill sensors.

Pre-Installation Requirements

When choosing a location to install the IntelliCheck®3R System, these guidelines must be followed:

- Appropriate industry, national, state and local codes.
- The National Fire Protection Agency (NFPA) Code (USA).
- Practical considerations within the jurisdiction of this code.



🔼 Warning:

Before beginning installation, the tank compartments must be completely drained of liquid and be vapor-free.



🗥 Warning:

The metal enclosure must be connected to the metallic chassis. which ultimately connects to the negative terminal of the battery, of the vehicle to establish proper electrical grounding.

2.1 IntelliCheck®3R and Socket Installation

The IntelliCheck®3R housing and the socket housings should be mounted to clean, bare surfaces on a metal bracket mounted to the vehicle frame (chassis).

- The use of a bracket welded to the frame is recommended.
- The area where the mounting bracket and frame connect should be free of all paint, dirt and oils. This will allow a solid bond between the frame and the IntelliCheck®3R and the socket housings.
- The mounting plate surface area under the lock washers and the nuts used for the mounting plate (for IntelliCheck®3R and the socket housings) should be clean and free of paint so that a good electrical contact is made to the housings.
- The IntelliCheck®3R and the socket housings should be mounted in an area that is centrally located to accommodate the plug connection from the loading rack.

2. Mechanical Installation

- The IntelliCheck®3R can be installed inside a tool cabinet on the side of the truck.
- The IntelliCheck®3R does not necessarily have to be located beside the socket housings, but mounted in an area that is visible to the operator as well as accessible to service personnel.
- Clearance around the module is needed for the installation of conduit entrance compression fittings used to secure the power and signal cables.
- It is important to remember that the connection of the socket housing to the frame should be a solid bond, less than 0.25 ohm.





Warning:

No drilling or welding to the tank's frame should take place without first consulting the tank manufacturer.

- The use of stainless steel mounting bolts and hardware is recommended (5/16" or M8).
- The housing should be placed over the area where the IntelliCheck®3R will be mounted and the mounting hole locations should be marked, aligning the drilled mounting holes for proper installation.

2. Mechanical Installation





Conduit / Cable entry holes: 1/2" NPT

2.2 Overfill Sensors Mounting

The SP-TO sensors should be mounted in each compartment to permit accessible, in-place testing after the initial installation is complete.

- Make sure that the sensor's sensing level is properly located in relationship to the Weights and Measures marker (if installed) in each compartment.
- Refer to the Sensor's installation instruction for guidance.

3. Electrical Installation

Note:

We strongly suggest the use of a Scully IntelliCheck®3R wiring installation kit. Wire installation kits include conductor cable, cable compression fittings, on/off switch, and crimp-on connectors.

Refer to the Appendix for detailed electrical connections. The diagrams illustrate wiring for ONE compartment with high sensor connected to TB5, high-high sensor connected to TB4 and IntelliCheck®3R output connections for both Two-Wire Optic (green) (called Thermistor) and Five-Wire Optic (blue) vehicle-mounted sockets.

- Sensor connections to TB5 only consist of the ONE actual high compartment sensor installed.
- Sensor connections to TB4 only consist of the ONE actual high-high compartment sensor installed.
- All wire splices should be made in the watertight sensor holder junction boxes to facilitate service replacement of sensors and to prevent premature wiring failures due to corrosion.
- Continuity of the compartment sensor wiring to the appropriate compartment designation at TB4 & TB5 must be maintained to aid in the ease of diagnosing system faults. The best way to do this is to use color-coded wires matching the wiring diagrams in the Appendix of this manual.
- To make wiring easier, remove the IntelliCheck®3R Electrical Module. Make note of the electrical GND wire to the mounting stud at the top of the electrical module. Remove the screws the electrical module from the outside metal enclosure during this part of the installation and place it and the hardware in a safe place until needed.



Do not, under any circumstances, mix Intrinsically Safe (I.S.) with Non-Intrinsically Safe (Non I.S) wiring in the same cable/conduit entrance. Refer to Control Drawing 61667.

3. Electrical Installation

1. Remove all the plastic pipe plugs on the conduit entry ports of the IntelliCheck®3R. Seal plugs must be reinstalled for unused ports after wiring is completed. IntelliCheck®3R is designed to use a compression fitting for each port. After running the electrical cable/conduits pull all the necessary wires for the installation into the enclosure from the installed sensors, power, and any auxiliary devices such as hose interlock and valve shutoff connections to the appropriate ports. Leave about 5 inches (12.7cm) of wire in the enclosure. Do not strip or attach any wires at this time. If not using colored wires make sure to number each wire accordingly from each place and device as pulled.



2. When all the wires are secure in the appropriate port, pack the fitting with an approved weather sealant or silicone RTV and tighten the compression fitting. This will fill air space that may allow condensation to enter the housing and corrode the wire contacts.



Warning:

Do not gather and splice wires in the IntelliCheck®3R enclosure housing. Wire splices should be made in external watertight junction boxes.

Water Proofing:

To avoid future maintenance issues regarding water infiltration into the housing via the electrical cable/conduit entries, Scully strongly recommends the following precautions:

1. Long vertical cable/conduit runs into the sides of the enclosure should be minimized as they promote water channeling to the cable/conduit gland/seal fitting packing.

3. Electrical Installation

The cable/conduit glands on the sides of the enclosure should be very carefully installed, taking extra precaution to make certain that the installation is properly sealed (as required by code).

Note:

Most of the failures seen are because of water ingress into the earlier IntelliChecks[®]. The cause of this is poor or insufficient sealing of conduit openings. Scully provides wire cable and gland/seals parts and kits, which are matched to assure a seal.

A. North American Installations


To maintain NEMA 4 rating, all NPT threaded joints of Cable glands or conduit should be wrench tight.

B. European Installations

To maintain the IP65 ingress rating of the enclosure, the cable gland fittings at all entries to the enclosure should be equipped with a fiber washer or O-ring between the cable gland and the enclosure.

Note:

To prevent corrosion from making it difficult to remove a plug or cable gland, use a copper based or petroleum based anti-seize/sealant (2g tube included). Future changes, maintenance or upgrades to the equipment can be made easier if this step is performed.



3. Electrical Installation


3.1 IntelliCheck®3R Power Wiring




Warning:

To ensure proper voltage and grounding, it is strongly recommended that the power and ground wires run directly from where the power and ground enter the trailer/vehicle. Do not rely, only, on mounting the Intellicheck®3R to the chassis to get a ground connection. If a fuse and or an optional power on/off switch is installed, they should be located in the truck Cab or close to where the power wire enters the trailer/vehicle and not in the hazardous area where the Intellicheck®3R is installed.

- Connect power to the module. We recommend the use of 1mm² (18-AWG) gauge wire or the Scully cable using only the red and black wires. (The Scully cable in 5, 7, and 11 conductors, all use the same cable gland.)
- Feed the cable through a compression fitting and insert through Port A on the IntelliCheck®3R.




- Strip about 6mm (1/4")off each end of the black and red wires.
- Insert the exposed black wire into the TB1-2 GND contact #2 and tighten.



3. Electrical Installation

- Insert the exposed red wire into the TB1-1 12/24V contact #1 and tighten.
- On the IntelliCheck®3R check that the Green with yellow stripe wire's ring terminal from TB1-3 is placed under the potted module's mounting screw



 The use of an in-line fuse (supplied with the IntelliCheck®3R) between the vehicle power and the TB1 12/24 V is highly recommended.

Note:

The fuse should be located in a non-hazardous area or zone on the vehicle. This provides protection against a short in the wiring to the IntelliCheck®3R.

 A 1/2-AMP fuse is recommended for the fuse connections.
 After making this connection, it is a good idea to use an ohm meter to make sure no short exists between 12/24V and GND of TB1.

3. Electrical Installation


3.2 Truck Sensor Wiring - General

General wiring guidelines are presented here, for specific instructions please refer to the installation manual shipped with the sensors.

1. Connect a compression fitting to each conduit entrance hole on the high-high sensor holder. The high sensor holder (compartment number 1 holder), will only need a single compression fitting in one of the entrance holes, the other should be blocked-off with the supplied plug M20 x 1.5 plug (or 1/2" NPT). Measure the cable from holder-to-holder, taking into consideration that enough cable should be left at each end (approximately 25 cm (10")) for wiring.

Cables should be measured, to allow them to be brought out at right angles to the rollover rails.


Overfill Sensor Wiring Diagram



3. Electrical Installation

2. After the cable has been measured and cut for each run, strip back approximately 22 cm (8.5 inches) of the outer cable insulation, exposing the inner conductors, and feed the cable through the compression fittings and tighten. It is a good idea to apply a small amount of silicone RTV sealant to the outside of the cable before pushing it through the compression fitting. This will fill any small air space that may be left after tightening the compression fitting around the cable. This will also prevent condensation from seeping through. At the last compartment sensor, feed a length of the Scully cable down the back of the vehicle. Be sure to neatly anchor the cable as you go to the IntelliCheck®3R monitor.

Cable Sealing Diagram



4. On-Vehicle Programming

There is no need to perform programming of the Intellicheck®3 Dual-Level model. The Intellicheck®3R Dual-Level is pre-programmed at the factory for ONE compartment. There will be one High sensor and one High-High sensor in compartment 1.

Note:


The IntelliCheck®3R Dual-Level unit is pre-programmed at the factory for operation with one High and one High-High Scully SP-TO Two-Wire Optic sensors.

The On Board Programming function for the Intellicheck®3R Dual-Level model is disabled. Only one compartment is supported.

There is only one sensor configuration supported, Two-Wire optic sensors. Follow the directions in the wiring section to correctly wire your sensor configuration.

5. Sensor Wiring

 Feed the cable through the bottom left-hand corner compression fitting (Port D) to allow approximately 12.5 cm (5 inches) of cable into the IntelliCheck®3R housing.




- Strip back 10 cm (4 inches) of the outer insulation, exposing the color-coded wires inside.
- Do not tighten down the compression fittings until you have made the appropriate wiring connections as detailed in the wiring diagram at the end of this manual.

5.1 Two-Wire Sensor Wiring

- 1. Connect all sensor wiring to TB4 per drawing on opposite page.
- 2. Turn on Power.
- If necessary, correct any sensor wiring problems or faults shown by the compartment indicators (refer to Operations Section)

5. Sensor Wiring




2-Wire Dual-Level Liquid Level Sensors

6. Socket & Switch Wiring

Refer to the Appendix for the wiring diagram and for wiring port location. Port H is for the Five-Wire Optic and Two-Wire Optic socket connection.

- Remove all the pipe plug(s) along the right side conduit entry ports of the IntelliCheck®3R.
- Install compression fitting in Port H.




- Feed the Scully cable through a compression fitting for each socket into Port H. Leave about 3 inches of extra cable inside the IntelliCheck®3R housing for connection and future service.
- Run the cable(s) to the socket(s), anchoring the cable in a neat fashion where needed.
- Install a compression fitting into one of the conduit entrance holes that will best suit the installation.
- Feed the cable through a compression fitting approximately 5 inches (12.7cm) into the socket housing.
- Strip back the cable insulation cover to expose the color-coded wires.

6. Socket & Switch Wiring

6.1 Five-Wire Optic Connection

Rear View SJ-6SO or SJ-6W




Pin 9 for both sockets is for Ground Bolt if so equipped

- Connect the cable wires by their appropriate color to the corresponding pin numbers of the socket according to the socket style and type, Five-Wire Optic or Two-Wire Optic (Thermistor).
- To make pin connections, strip about 6mm (1/4") off each cable lead exposing the wire inside

6. Socket & Switch Wiring

6.2 Two Wire Optic (Thermistor) Connection



Pin 9 for both sockets is for Ground Bolt if so equipped

- Loosen the pin set screw. Slip the exposed wire into the pin and tighten the set screw.
- As previously recommended, it is a good idea to apply a small amount of silicone RTV sealant around the outside of the cable before pulling it through all the way. This will fill air space that may allow condensation to enter the housing and corrode the wire contacts.
- Tighten all compression fittings.
- At the IntelliCheck®3R, connect the socket leads by their appropriate color.
- To make the connection, strip about a 6mm (1/4") off each cable lead.
- Slip the exposed wire into the corresponding number pin of TB6


Note:

Refer to Appendix for additional wiring diagrams.

6. Socket & Switch Wiring

6.3 Auxiliary Switch Input

There is an Intrinsically Safe (I.S.) auxiliary switch input available. A new factory unit includes a factory-installed jumper across the two terminals. If the jumper is removed, the AUX IN indicator illuminates and the IntelliCheck®3R system will not permit loading. This switch input can be used for end-user supplied switch inputs. For instance, a normally-open vapor recovery hose interlock switch could be connected to the terminals. Using this input, the IntelliCheck®3R unit will not permit until the vapor recovery hose is connected to the vehicle. The Auxiliary input can connect to multiple inputs by simply connecting all of these devices in series. Device wired to TB3 pins 1 & 2.




6.4 Non Intrinsically Safe (Non I.S.) Relay Output



Do NOT under any circumstances mix Intrinsically Safe (I.S.) with non-Intrinsically Safe(non-I.S.wiring).

IntelliCheck®3R provides a relay contact output on TB7 that can be used to drive a non-intrinsically safe load. The output can be used to switch a solenoid valve or another external relay (limit of 2 AMPs). Contact the factory for specific application.




6.5 Intrinsically Safe (I.S.) Relay Output



Do NOT under any circumstances mix Intrinsically Safe (I.S.) with non-Intrinsically Safe(non-I.S.wiring).


IntelliCheck®3R provides a relay contact output on TB6 that can be used to drive an intrinsically safe load. The output can be used to switch a solenoid valve or another external relay (limit of 2 AMPs). Contact the factory for specific application.



7. Cover Tightening

After all the connections to the module are made, apply a small amount of white lube or non-conductive grease to all of the connections at TB1, TB2, TB3, TB4, TB5, TB6 and TB7 (if used) to prevent corrosion.

Place the gasket, window and cover onto the housing and tighten in sequence as shown. After the cover is secure, power can be supplied to the unit for diagnostic evaluation.




Place the gasket, window and cover onto the enclosure housing and lightly tighten all twelve stainless steel hex bolts with lock washer. Repeat by firmly and evenly tightening to approximately 1.6 N-m (14 inch lbs) per bolt.

Do not over tighten. Do not use an impact wrench.

8. Operations

8.1 Sensor Diagnostics


Each sensor has an indicator light for its status located horizontally across the top of the module, behind the clear window of the housing. A quick reference for sensor diagnosis is listed on the outside cover. (Not only does the indicator show the status of a sensor condition, wet or dry, it also gives the sensor connection fault status and sensor operation fault indication as well.) The diagnostic indicators allow the user to diagnose any IntelliCheck®3R System problem quickly and efficiently without having to take Voltage or resistance readings to locate a fault.



8. Operations

The DUAL-LEVEL SENSOR indicator light conditions are as follows: (pre-programmed for ONE compartment)

DUAL-LEVEL



• **Green Light On** -Sensor is operating normally. (In this state, the **GREEN** permit indicator is on and the **DYNACHECK**® indicator is flashing.)

• **Red Light On** -Sensor is immersed in product. (In this state, the permit indicator is **RED** and the **DYNACHECK**® indicator is flashing.)



• **Light is OFF** -Sensor was not programmed to exist during OVP (on vehicle programming). (In this state, the **GREEN** permit indicator is on and the **DYNACHECK**® indicator is flashing.)



• Red Light Is Flashing Slowly (as compared to the DYNACHECK® Indicator) -The sensor return line connection is open. (In this state, the permit indicator is Red and the DYNACHECK® indicator is flashing.)



• Red Light Is Flashing At Medium Speed (equal to the DYNACHECK® Indicator) -The sensor circuitry is faulty. (In this state, the permit indicator is RED and the DYNACHECK® indicator is flashing.)



8. Operations


• Red Light Is Flashing Fast (as compared to the DYNACHECK® Indicator) -The sensor return line is shorted to ground or another return signal line. (In this state, the permit indicator is *RED* and the DYNACHECK® indicator is flashing.)



LED Status	Indication	Permission
00000000000	No Sensor Present	-
00000000000	Dry Sensor	Permit
00000000000	Wet Sensor	No Permit
00000000000	DYNACHECK® (Constant Blink Rate)	-
0000000000	Sensor Circuit Faulty	No Permit
	(Equal to DYNACHECK® Blink Rate)	NO Femili
00000000000	Sensor Return Line Open	No Permit
	(Slower than DYNACHECK® Blink Rate)	
00000000000	Sensor Return Line Shorted to Ground	No Permit
	(Faster than DYNACHECK® Blink Rate)	

Flashing = Dynacheck® rate Flashing Slow = ½ Dynacheck® rate Flashing Fast = 2x Dynacheck® rate

8.2 IntelliCheck®3 System Diagnostics



8. Operations

The IntelliCheck®3R controller has diagnostic indicators that report on several aspects of system operation. These diagnostics are:

• **PERMIT**- When this indicator is **GREEN** the IntelliCheck®3R System is indicating a permissive state to the loading rack terminal equipment.



When this indicator is **RED** loading of the truck is not permitted



DYNACHECK®- When this **GREEN** indicator is pulsing, the IntelliCheck®3R module is functioning. The pulsed indication signifies the IntelliCheck®3R System and its module are self-checking. Should the module indicate a faulty sensor, the **DYNACHECK**® indicator will continue to pulse as it constantly self-checks all other system components for proper operation. If not pulsing, than a fault exists or LED is burned out



• AUX IN - This indicator gives status of auxiliary switches or connections made to the IntelliCheck®3R System to satisfy loading operation requirements. When this indicator is GREEN it indicates that there is a closed circuit between the AUX terminals.



If this light is **RED**, an external switch connected between these terminals is open, and Permit will not be allowed (Non-Permit).



8. Operations

• RACK- This indicator gives the status of connection to the loading rack controllers. The indicator is **GREEN** when connected to a loading rack controller.

Or, the indicator is **RED** when not connected to a loading rack controller.



• **POWER**- This indicator gives status of power to the IntelliCheck®3R. If this light is **GREEN**, indicates a proper IntelliCheck®3R internal Voltage for proper sensor operation,

otherwise if the indicator is **RED**, all sensors are turned off and IntelliCheck®3R goes non-permit.




Note:

Failures such as broken or shorted wires, electronic component failures or intermittent connections, on the sensors will not allow the system to operate (non-permit) properly when connected to the loading rack controller. Steps should be taken using the previous information or the trouble shooting guide, to determine the area of fault and to take corrective action.


8.3 Technical Service


If for any reason a fault is not detected, but the vehicle still has problems loading, call Scully's Technical Service Department in the United States and Canada, at **1-800-272-8559**, 24 hours per day. Be sure to have the results of the tests you have conducted when you call for assistance.

9. Control Drawing





10. Appendix





10. Appendix






11. Parts List

COMPLETE ASSEMBLY



Part Number	Description	
09578	Intellicheck®3R Dual-Level Monitor - NPT	_
09583	Intellicheck®3R Dual-Level Monitor - M20	

REPLACEMENT PARTS



Item	Part Number	Description	Qty
1	09575	Cover Assembly (includes items 2 through 6)	1
2	32600	Cover	1
3	38041	Window	1
4	92000	Gasket, Cover	1
5	50151	Screw, Hex Head, 10-24 x 3/4", Stainless Steel	12
6	51122	Lockwasher, Split, #10, Stainless Steel	12
7	09567	Replacement Module, Dual-Level	1
8	32599	Base, 1/2" NPT Conduit Entries	1
9	31820	Switch Assembly N.O.	1
10	32365	Test Switch N.C.	1
11	50796	Pipe Plug, 1/2" NPT	8
12	31842	Standoff, Male-Female, 5/16" Hex, 10-32 x 7/8" Lg., Aluminum	4
13	26425	Fuse and Holder, In-Line, 1/2 AMP	1
	26427	Fuse Only	1

Scully - Setting Standards in Safety and Dependability since 1936.

For over seventy-five years Scully has been engineering and building products to the highest safety and reliability standards. We design and manufacture all of our systems under one roof to ensure complete quality control over our manufacturing and testing operations.

Scully is ISO certified and all of our products are made in the U.S.A. In addition, we back up our products with the best service in the industry. We have direct sales and service personnel in the U.S.A., The United Kingdom, and Europe and are represented in over 50 countries.

For more information and 24 hour technical assistance, call Scully Signal Company at 1-800-2SCULLY (1-800-272-8559)





Scully Signal Company

70 Industrial Way, Wilmington, MA 01887, USA 800 272 8559 • sales@scully.com • www.scully.com

61698 Rev C July 2023