



Universal Truck Tester

Road Tanker Overfill Prevention System Diagnostics



DESCRIPTION

The **Scully Universal Truck Tester** is the most advanced and comprehensive road tanker tester available. It checks the operation of road tanker overfill prevention, and self-proving earthing systems. Complete diagnostics limit the expense of downtime. The tester is compatible with the Scully IntelliCheck® Monitor series, Load Anywhere®, and independent Scully optic and thermistor road tanker sensors.

Once the tester is set up in a non-hazardous area, move the selector switch to the desired setting and connect the tester to the tank truck socket with the appropriate plug and cable. The test results will be shown clearly on the easy-to-read LED display.

TECHNICAL SPECIFICATIONS

Power Supply: 8 "D" Cell Batteries.
Battery Access: Remove 2 Screws in Front Panel.
Operating Temp Range: -25°C to +45°C (-13°F to +113°F).

Maximum number of compartments: 8.
Dimensions: 203mm x 152mm x 101mm.
Weight: 1.7Kg (3.8 lbs).
Approvals: None.

ORDERING INFORMATION	
Description Truck	Part Number
Scully Universal Tester (Order appropriate plug and cable with tester. "D" size batteries not included)	08938
PCAM, 10-Pole Scully Plug and Cable	08926
PCAM, 6-Pole WOGA Plug and Cable	08927
PCAM, 7-Pole J560 Optic	08928
PCAM, 4-POLE,1-CHAN, Plug and Cable	08936

Copyright © 2023 Scully Signal Company. Dynacheck, Dynamic Self-Checking, Dynamic Self-Test, Faylsafe, IntelliCheck, Intelliview, Load Anywhere, Maxsafety, are registered trademarks of Scully Signal Company. All Rights Reserved. Specifications are subject to change without notice.

02-8A
June 2023



scully

Scully Signal Company
800 272 8559
sales@scully.com
Wilmington, MA, USA

Scully Systems Europe NV
+32 (0) 15 56 00 70
sales@scully.be
Mechelen, Belgium

Scully UK Ltd
+44 (0) 1606 553805
sales@scullyuk.com
Winsford Cheshire, UK

Scully Systems India
+91 9821799566
salesindia@scully.com
Maharashtra, India

Dynamic Self-Testing® Overfill Prevention Systems

