





Setting Standards in Safety and Dependability since 1936.

Ventalarm® Signals

The First and the Finest

- Since 1936! The original Ventalarm tank fill signal is built to last.
- Used for above and below ground tanks.
- Version for a 90° pipe elbow available.



Tank Opening	Vent Pipe	Model #	Part #
1 1/4"	1 1/4"	VS 201	00201
1 1/2"	1 1/2"	VS 202	00202
1 1/2"	1 1/4"	VS 240	00208
2"	1 1/4"	VS 521	00215
2"	1 1/2"	VS 530	00216
2"	2"	VS 270	00209 
1 1/4" (90° Elbow)	1 1/4"	VS 230	00227
2"	2"	*16 1/2" - up to 2,000 gal.	00272
2"	2"	*21 3/4" - greater than 2,000 gal.	00274
2"	2"	For 275 gal. vertical and flat tanks	00275 

**For cement vaulted tanks*

Compression Ventalarm® Signals
The Whistle-Stop for Existing Installations

Tank Opening	Vent Pipe	Model #	Part #
1"	1"	VS 224	00205
1 1/4"	1 1/4"	VS 220	00203
1 1/4"	1"	VS 221	00204
1 1/2"	1 1/2"	VS 229	00207
2"	2"	VS 275	00213
Gasket Kit	1"	VS 224/221	10269
Gasket Kit	1 1/4"	VS 220	10266
Gasket Kit	2"	VS 275	10328



Note: Compression Ventalarm Signals are not for use in underground tanks.

Remote Ventalarm Signals

Tank Opening	Vent Cap	Model #	Part #
1 1/4"	1 1/4"	VS 921	00219
1 1/4"	2"	VS 924	00221
*Special	1 1/4"	VS 926	00223

**Fits into hole drilled into tank when no opening is available.*

Large Tank Remote Ventalarm Signals

Description	Model #	Part #
Vent cap, 2" pipe, heavy duty	VC 127	00255
Intrusion, 2" thread	VC 113	10059
Whistle signal, 3/4" line	VC 153	10071
Complete assembly	VC 119	00233

Large tank remote signals require a 3/4" line for heavy oils - not supplied by Scully.

Remote signals require 3/8" copper tubing to connect to whistle - not supplied by Scully.

December 2025

